

Vande Graff Generator

(High-voltage Electrostatic Generator)

(J2311)

4. Direction

1. The surface of storage ball, belt pulley, rubber belt, polyethylene methacrylate tube and discharge ball should be kept clean and dry. If it is dirty, clean it with soft cloth.
2. Adjust screw 2 and rubber belt 6, so as to make the rubber belt in proper tightness.
3. Put electricity collection comb as near to the rubber belt as possible but can't touch it.
4. Insert the wire of discharge ball into ground socket. If power switch operate the machine for few minutes. Turn on the switch 8 when necessary to reduce humidity inside this machine. If the trial shows that the machine is OK, you can operate it.

5. Maintenance

1. Loosen the rubber belt after operation and put it in dry and clean place.
2. When high humidity, it is forbidden to use fire for the reduction of humidity, in order to avoid damage and deformation.

6. Remarks

1. Quality is guaranteed. If the product is not up to the requirement, the supplier under-takes to repair it free of charge in one year.
2. If any damage arises from poor package, it's the supplier's duty to compensate for the loss.